



www.ehcteknik.com

Assembly Instruction EHC HT10 Light

Head Office

Sweden

EHC Teknik ab

Ögärdesvägen 8a

S-433 30 Partille

Tel.: +46 (0)31 449020

Email. office@ehcteknik.se

www.ehcteknik.com

Benelux

EHC Teknik bvba

Karel Soetelaan 37

B-2150 Borsbeek

Tel.: +32(0)3 3663936

Fax .: +32 (0)3 3662633

Email. info@ehcteknik.be

www.ehcteknik.be

www.ehcteknik.nl

www.ehcteknik.fr

Deutschland

EHC Teknik GmbH

Eiserfelder Str.316

D-57080 Siegen

Tel.: +49 (0)271 3177936

Fax .: +49(0)271 3177937

Email. buero@ehcteknik.de

www.ehcteknik.de

Description EHC HT10 Light filter

EHC HT filter for diesel engines.


The HT filter is rust protected by zinc. Coating.

The unit can be mounted horizontal or vertically.

Maximum temperature, exhaust: 250°C

Mounting:

1. The unit is mounted using the two clamping rings (1), to the intended machine.
2. The mechanical pressure guard (1) vents when filter replacement is necessary. Replace the membrane of the pressure guard when the filter cartridge replacement is made.



Important! Mount the device vibration-free


For the measurements of the filter unit and connections, see technical data

Filter replacement




Warning:! Filter may be hot at filter change.

1. Loosen eccentric locks (1) on the filter housing.
2. Remove the filter element (2) from the filter container (3) and insert the new filter cartridge.



The used filter can be disposed of as combustible waste.

Electrical pressure switch 12/24V (Option)



Important! Beware of not breaking the moisture blocking sealing on the guard at the assembly.




Important! Mount the delay relay protected in the cabin IP54)

The electrical pressure switch has a buzzer that sounds and a lamp that lights up when filter change is necessary. Pressure switch (4) is screwed into the existing socket on the unit as image.

Electrical connection + linked to the ignition switch, and - to the battery.

Mount the coupling device according to IP54¹.

1. Delay relay, ~2min.
2. Buzzer
3. Lamp
4. Pressure switch
5. Fuse, 2A



Mechanical pressure guard, Standard

The mechanical pressure guard (1) vents when filter replacement is necessary. Replace the membrane of the pressure guard when the filter cartridge replacement is made.

[1] IP54=Dust cover and withstand water spray from all angles

Technical data:

EHC HT Filter separates >99% (>0,12μ) of the particles in the exhaust.

Maximum temperature, exhaust: 250°C

Max. K-Value recommended: 1.3

Weight: 6kg

Life expectancy depends on engine size, engine type, the engine used and engine condition.

EHC HT Filter meet the exhaust requirements:

- TÜV Fahrzeug GmbH, S-129.99.001.00
- TRGS 554 (D)
- VERT Filter List: B416/06.15 (CH)
- COSHH (GB)

